



## SAFETY GUIDE

### SONTE Film Installation Precautions

#### Follow our procedures

Follow our SONTE Film Installation Guide and Clips-On Installation Video to avoid damage to this product.

**IMPORTANT: Use only the tools we suggest in our user guides to prevent damage to the product and/or injury.**

#### Installation

To avoid electric shock or damage to SONTE Film, do not install the product where the window frame material is metal or can conduct electricity.

Always leave a 2-3mm (0.07-0.12in) gap between SONTE Film and the window frame.

**IMPORTANT: If you need to install SONTE Film on a window with a metal frame, always leave a 2-3mm (0.07-0.12in) gap then apply non-acid based silicone along the edges (including silicone around Clips-On) as per Step 17 of our SONTE Film Installation Guide.**

### General Safety Summary

Review the following safety precautions to avoid injury and prevent damage to this product or any products connected to it.

#### Injury Precautions

To avoid fire hazard, use only SONTE provided power cables specified for this product.

#### Avoid Electric Overload

To avoid electric shock or fire hazard, do not apply a voltage to a terminal that is outside the range specified for that terminal.

#### Ground the Product

This product is grounded through the grounding conductor of the power cord. To avoid electric shock, the grounding conductor must be connected to earth



ground. Before making connections to the input or output terminals of the product, ensure that the product is properly grounded.

**Do Not Operate Without Covers**

To avoid electric shock or fire hazard, do not operate this product with covers or panels removed.

**Do Not Operate in Wet/Damp Conditions**

To avoid electric shock, do not operate this product in wet or damp conditions.

**Do Not Operate in Explosive Atmosphere**

To avoid injury or fire hazard, do not operate this product in an explosive atmosphere.

**Product Damage Precautions**

Make sure the input voltage matches the AC input specs of the power supply.

**Provide Proper Ventilation**

To prevent product overheating, provide proper ventilation.

**Do Not Operate With Suspected Failures**

If you suspect there is damage to this product, have it inspected by SONTÉ's qualified service personnel.